


*Based on the Android phone, different Brand and Model may differ.





Successfully Added

After you connect, the network is "Saved." When your phone is near and Wi-Fi is on, your phone automatically connects to this network.



Troubleshooting Tips

Forget a network, so Android Phone doesn't join it automatically: Choose Wi-Fi and tap next to a network you've joined before. Then tap "Forget this Network."

Reset the network settings on iPhone: Choose Settings > General > Reset > Reset Network Settings.